

Committed to providing innovative solutions for material surface treatment.

NE-PE40F

40L (13.56Mhz) LOW-PRESSURE PLASMA TREATMENT SYSTEM





Shenzhen Naen Tech Co., Ltd

Website: www.cnplasma.com

TEL: (+86) 0173-0267-6848


Email: naentech.plasma@gamil.com

NE-PE40F PROFILE

NE-PE40F is a large-scale industrial low pressure plasma treatment system, equipped with high power, large cavity, high density, high stability, for large-scale continuous production. It is used in a wide range of fields, from the manufacture of semiconductors and electronic components to medical applications. Plasma treatment cleans materials by decomposing and vaporizing microscopic organic matter adhering to the material surface. It also has the effect of surface modification by breaking molecular bonds on the material surface and changing the surface composition. In addition, the plasma decorates the surface of the material with hydroxyl groups, making it hydrophilic and less likely to repel liquids.

It is widely used in scientific research institutions, enterprise R&D units and small batch production, including:

- Plasma cleaning organics
- Plasma surface activation to improve adhesion
- Form new functional groups and improve hydrophilicity
- Wafer Cleaning, remove the photoresist
- ITO & FTO & Glass & Pottery & Metal
- ❖ PP & PET & PVC & PEEK & PC



NE-PE40F FEATURES

♦ AIO, small and exquisite

Weight:300KG Size:685mm(L)X830mm(W)X1450mm(H)

♦ Adjustable power settings

Solid-state RF power supply can be adjusted from 50W to 500W continuously.



Shenzhen Naen Tech Co., Ltd

Website: www.cnplasma.com

TEL: (+86) 0173-0267-6848

Email: naentech.plasma@gamil.com

♦ Special cavity mechanism and discharge electrode for CCP &RIE

The unique design of the chamber can adjust the distance between the electrodes, adjust the plasma intensity and density, greatly improve the processing capacity and efficiency, and ensure uniformity.

♦ Self-developed power supply

Digital high-frequency plasma generator produces high-density contour particles to ensure outstanding cleaning effect.

♦ MFC high precision control of gas flow

Two gas channels are standard, supports various process gases, such as oxygen, argon, hydrogen, nitrogen, etc.

♦ Pro-environment

Dry processing, low gas emission, no hazardous emissions, no pollution to the air.

Aviation-grade aluminum alloy cavity

Durable high-quality aviation-grade aluminum alloy dedicated electrodes with tray.

Size: $350(L) \times 405(D) \times 300(H)$ mm; 42L

♦ 7" Touch screen

The whole process can be directly set and processed through the touch screen, which is intuitive and the process can be monitored in real time.

♦ Vacuum pump

Equipped with a high-speed vacuum pump, the ideal vacuum value can be reached within 90 seconds, saving the entire processing time.

♦ Fast treatment time

A cycle only takes three to five minutes, and processing times can be set according to demand, with a maximum processing time of 9,999 seconds.

NE-PE40F SPECIFICATIONS

| | STANDARD MODEL | OPTIONAL | |
|----------------------------|--|-----------------------|--|
| Overall dimensions | | | |
| Size | 685mm(L)X830mm(W)X1450mm(H) | | |
| Weight | 300KG(Including vacuum pump) | | |
| Plasma generator | | | |
| Power | 50-500w(Adjustable) | | |
| Frequency | 13.56Mhz | | |
| Radiation-resistant | High-speed automatic matching within 0.1s, network | | |
| high-frequency matcher | communication supported | | |
| Vacuum chamber | | | |
| Cavity material | Aviation-grade aluminum alloy | | |
| Cavity size | 350(L)×405(D)×300(H)mm; 42L | | |
| Effective processing range | 300(W)x 300(D)x34(H)mm | | |
| Layers | 4 | Specified by customer | |



Shenzhen Naen Tech Co., Ltd


Website: <u>www.cnplasma.com</u> Email: <u>naentech.</u>

Email: naentech.plasma@gamil.com

TEL: (+86) 0173-0267-6848

| Discharge electrode | | |
|-------------------------|--|-----------------------|
| Electrode | High conductive aluminum alloy special electrode | |
| Discharge modes | CCP & RIE | |
| Gas Control | | |
| Gas flow controller | MFC | |
| Flow value | 0-500 SCCM | Specified by customer |
| Gas channel | 2 channels(supports various process gases, such as | 3 & 4 &5 & 6 channels |
| | oxygen, argon, hydrogen, nitrogen, etc.) | |
| Vacuum measurement | | |
| Vacuometer | Pirani | |
| Pumping system | | |
| Pumping speed | Oil pump | Dry pump |
| Limiting vacuum | 1PA | |
| Operating vacuum degree | 10-50Pa | |
| Control system | | |
| Touch screen | 7'' | |
| PLC | Siemens | |
| Software | Plasma control system with independent patent: 3 - level | |
| | permissions, auto/manual modes, recipe param | |
| | setup/storage/call, alarm history query, IO monitoring. | |
| Real-time monitoring | Power, vacuum degree, air pressure, gas flow rate, | |
| | working hours, etc. | |
| Alarm function | Vacuum anti-misoperation, power anti-misoperation, air | |
| | pressure alarm, phase sequence alarm | |
| Condition | | |
| Power Supply | AC380V,50/60Hz (Three-phase five little system,100A) | Specified by customer |
| Type of air pipe | Ф 8mm | |
| Gas purity | 99.999% | |
| Air pressure | 0.6-0.8Mpa | |
| Exhaust port | KF40 | |

TYPICAL PROCESS RESULTS





Shenzhen Naen Tech Co., Ltd

Website: www.cnplasma.com

TEL: (+86) 0173-0267-6848

Email: naentech.plasma@gamil.com

ABOUT NAEN TECH

Naen Tech are an international leader in the design, development and manufacture of plasma surface treatment systems & advanced plasma processes.

Our products are installed worldwide and trusted to deliver consistent, reliable results in both leading research institutes and in critical manufacturing steps.

We are experts in plasma technology and surface science. We are trusted partners, valued for our courtesy, professionalism and dedication to delivering the correct solution for our clients.

OUR SERVICES

Contract plasma treatment

We have more than 10,000 customer cases around the world, and we are equipped with technicians who can meet the plasma needs of various industries, and will provide a quick, no-nonsense feasibility solution for the surface treatment needs of different segments!

Surface testing laboratory

With a comprehensive suite of surface analysis equipment, we are able to conduct a wide range of surface property tests, both before and after plasma treatment, in order to provide you a professional report with the whole pictures and videos.

After sales support

The equipment is guaranteed for one year free of charge and provides lifetime technical services.

If the equipment fails (non-human damage), we will arrange after-sales personnel to follow up within 24 hours until the fault is eliminated.

Rental plasma systems

We carry a wide range of our standard equipment in stock and available for short or long term hire. This is particularly useful for in-house proof of concept trials or to satisfy short term contract work.

Method development

We have invested significantly in laboratory facilities to assess, test and investigate all aspects of plasma surface modification on a wide range of materials. Coupled with extensive in-house and real-world knowledge, we can usually deliver a tailored treatment quickly and efficiently to suit your individual product or production needs.



Shenzhen Naen Tech Co., Ltd TEL: (+86) 0173-0267-6848

Website: www.cnplasma.com Email: naentech.plasma@gamil.com